

Window Weld Mounts (DIY)

DIY UNDER CREATION - DO NOT ATTEMPT UNTIL THIS IS FINISHED OR DO SO AT YOUR OWN RISK

1. Drill out mount where fluid is contained in the mount.



2. Use a syringe to inject [3M Window Weld](#)

3. Let cure for 24-48 hours.

Failure to let it cure will likely result in part failure.

4. Re-install

Revision #10

Created 17 February 2024 01:36:05 by Akakios

Updated 6 June 2024 03:27:37 by Akakios