

# Adjust LED Brightness

[09 – Cent. Elect.] [Security Access - 16] (enter security code. One of the default codes is- 20113)

[Adaptation - 10] -> Channel 3

Set between 5 and 100

---

Revision #1

Created 2 March 2024 22:10:01 by Akakios

Updated 6 June 2024 03:28:52 by Akakios