

Disable Entry Warning Beeps

1. Module 46
2. Adaption, enter channel 98
3. Change 1 to 0

Part Two

1. Module 46
2. Coding, long coding helper
3. Byte 15, 00001111
4. Save exit and done
5. My byte 15 was showing 00000000 originally
6. Added the 4 1's, saved, coding accepted, power off car and restart.

<https://www.youtube.com/watch?v=Md7C2n1qQ24>

Revision #3

Created 2 March 2024 22:35:54 by Akakios

Updated 6 June 2024 03:28:55 by Akakios